

American MFE®

1 Enterprise Ave., Isanti, MN 55040 763-444-9225 800-328-4631 Fax 763-444-7890

Winch Mount Installation Instructions #1215-#1215R Honda Forman S/ES (Part #1900 Roller Fairlead Optional)

Hardware:

(2) 1" U-Clamps
(4) 5/16x 2" Hex Bolts
(10) 5/16" Flat Washers
(2) 5/16" Lock Washers

(2) 3/4" U-Clamps
(2) 8mm x 25mm Hex Bolts
(4) 5/16" Nylock Nuts
Plate

Remove the middle two 8mm hex bolts that mount the front bumper to the main frame. Secure winch to mount and slide complete unit under front fender between bumper tubes so that the winch and the mount are positioned so the middle mount tabs of the winch mount lines up with the two bolt holes that you remove. Install the two 8mm x 25mm hex bolts and 5/16" flat washers provided.

DO NOT tighten yet, make sure no chassis wires are being pinched. If so then move them out of the way.

Now place the two 1" U-Clamps that mount the top of the winch mount around the tube from inside out and under the winch plate use the 5/16x 2" Bolts and nuts.

Now take the two 3/4" U-Clamps and install them around the middle of the bumper support from the outside in, and under winch plate and use the 5/16x 2" Bolts and nuts tighten all bolts securely.

Attach Roller Fairlead to the front of the mount using two 5/16x 1" hex bolts, 5/16" Flat Washers and 5/16" Nylock Nuts (roller should turn freely.) NOTE: Bottom roller may need to be removed to run wire rope through and make sure winch rope feeds out from the bottom of winch, using instructions that were provided with the winch wire accordingly.

