

Winch Mount Installation Instructions
#1320- #1320R Kawasaki Prairie 360
(Part #1900 Roller Fairlead Optional)

Hardware:

- | | |
|--------------------------------|-----------------------|
| (8) 1/4" Flat Washers | (8) 1/4" Nylock Nuts |
| (1) Winch Mount Plate | (8) 1/4" Flat Washers |
| (4) 1/4x 1 1/8x 1 3/4" U-Bolts | |

Slide winch mount bracket behind front bumper and below the horizontal support tube with the roller fairlead pointing down and to the front of the ATV.

Place the four 1/4x 1 1/8x 1 3/4" U-Bolts over the top of the horizontal support tubes and through the winch mount bracket. Install the 1/4" Flat washers and 1/4" Nylock Nuts and tighten firmly.

Install the winch upside down making sure the winch winds correct direction.
Run wire rope through roller fairlead (rollers should turn freely.)

NOTE: Bottom Roller may need to be removed to run wire rope through. Using instructions that were provided with the winch wire accordingly.

