



1 Enterprise Ave., Isanti, MN 55040 763-444-9225 800-328-4631 Fax 763-444-7890

# 1865 2006 Arctic Cat Prowler

## Rear Winch Mount Installation Instructions

### Hardware:

(4) 5/16 x 1" Hex Bolts

(4) 5/16" Nylock Nuts

(8) 5/16" Flat Washers

1) Attach Winch to Winch Mount with hardware provided by Winch Manufacturer.

(2) Place Winch Mount with Winch in place on to the Frame cross supports. (per illustration) Line up Bolt holes with holes in Frame cross supports and bolt down using the four 5/16 x 1" Hex Bolts, Washers and Nylock Nuts. Tighten Securely.

3) Wire Winch per Manufacturer's instructions.

