



Synthetic Rope/Cable Installation Instructions

Your synthetic rope/cable comes from the factory ready to install on your winch. Please follow these instructions for mounting. These instructions are for mounting the rope/cable on a Gorilla Winch. Mounting the rope/cable on other winches may require additional modifications. The rope/cable is dyed blue at the factory. The blue dye will cure with time. But we suggest you use gloves during the rope/cable installation and during use to prevent the dye getting on your hands until it cures.

1. Remove the existing rope/cable from the drum on your winch. This may require releasing the clutch and un-spooling the existing cable. Be careful of burrs on steel cables. We suggest you wear protective clothing including gloves.
2. Insert the rope/cable through the small opening on the winch drum and push through to the other side of the opening (you may need to use a small screw driver or other tool to push the rope/cable through the hole).
3. Wrap the end of the rope/cable around the lower part of the drum.
4. Bring the cable around the drum and over the top.
5. Insert the rope/cable under the rope/cable where it comes out of the drum hole.
6. Snug the end of the rope/cable under the rope/cable where it exits the drum hole so it depresses into the opening in the drum.
7. Pull the rope/cable (long part) snugly to secure the rope/cable to the drum.
8. Your rope/cable should now be securely attached to the winch drum.
9. Recoil the rope/cable onto the drum with using the In-Out winch controls. Remember to keep tension on the rope/cable and wind the rope/cable so it lays flat against the drum.
10. If you have excess rope/cable for the size of your winch drum, you may need to trim the rope/cable to ensure it fits on your winch drum.

