



7/26/2006

GEN4 & ATP Polaris Winch Mount

PART# GEN4-POL

Kit Components:

<u>Qty</u>	<u>Part Description</u>
1.....	Winch Mount
6.....	1/4-20 U-Nuts
6.....	1/4-20x HH Bolts
6.....	1/4" Flat Washers
2.....	5/16-18 x 1.00"HH Flanged Bolts

INSTALLATION INSTRUCTIONS:

1. Loosen {do not remove) the two upper front bolts (A) of the ATV's brush guard.
2. Remove the six original Phillips head screws (B), and retain the side plastic shrouds and discard.
3. Remove the two original upper rear bolts (C) of the ATV's brush guard and discard.
4. On the plastic shrouds remove the OEM U-Nuts and replace them with the Supplied threaded U-Nuts (D).
5. The ATV's brush guard is loose and has adjustments so that you can move the brush guard in and out to line up all eight holes
6. Place the mount in position and attach the mount, with the topholes first using the supplied 5/16 bolts (G)." *Do not tighten*".
7. Once the two top bolts are started you can reassemble the plastic shrouds using the supplied bolts (E) and washers (F) "*Do not tighten*".
8. Once all eight bolts are started you can tighten them.
9. Using the instructions with your Winch and Fairlead assemble and wire accordingly.

