

# DROP BASKET INSTRUCTIONS



## **Assembling the Drop Basket**

Lay out the 6 sections on the ground like in figure 1. The tailgate will only have 2 bolt holes which go on the bottom side of the basket. Also, the Gorilla logo on the side pieces should show on the outside of the basket.

Check to make sure all of the plastic plugs are in the ends of the tubing. Look in the packaging for any missing plugs.

Using the Allen wrench and bolts, begin assembly of the basket. You may use some form of lock-tight if you wish to prevent the basket from loosening.

## **Mounting The Drop Basket**

Place the assembled drop basket on top of the rear rack of your ATV. While holding the basket in place, look for places to place the supplied metal cross-over washers. It may be helpful to have some help to hold the drop basket in place.

Slide the appropriate length Philips head bolt, through the metal cross-over washer, then the basket mesh or 1 inch basket tubing, and attach to the plastic mounting bracket as shown in figure 4.

Repeat 3 more time to secure the drop basket to the ATV.



# DROP BASKET INSTRUCTIONS



fig 1.



fig 2.



fig 3.

Part s Des cription	Qty
Left Side	1
Right Side	1
Contour ed rack	1
Tai l gate	1
Baske t bottom	1
Rack fro nt	1
Pin	2
Cable	2
Phillips Head s Bolts (55mm)	8
Phillips Head s Bolts (88mm)	8
Nuts ( 6mm)	8
Allen Head B olts (63mm)	14
Tube Plugs (shaped)	14
Tube Plugs (flat)	2
Metal Cross -Over Washer	4
Plastic Mo unting Bracket	4