



PROMARK OFFROAD

Polaris Ranger 2005-2008, 2x4, 4x4, and 6 x 6 Rear Bumper Installation

This Kit includes:

1. Rear Bumper (1)
2. Bumper Support Brackets (2)
3. 3 3/4" Long Bolts (2)
4. 7/8" Long Carriage Bolts (8)
5. Flat Washers (8)
6. Nylock Nuts (10)
7. Instruction Manual (1)

1. Mount the left bumper support bracket to the left rear of the frame (square holes under the tailgate) using two 7/8" long carriage bolts, two flat washers and two nuts. Repeat for the right side.

2. Insert the bumper mounts inside of the bed frame "U" brackets. It may be easier to start with the bumper at a 90 degree angle and tap into place. Attach with two 3 3/4" long bolts and two nuts.

3. Attach the bumper to the bumper support brackets mounted in step 1 using four 7/8" long carriage bolts, four flat washers and four nuts.

4. Check and tighten all bolts to ensure a secure fit.

