



# PROMARK OFFROAD

## Polaris Sportsman 2005-2009 400/450/500 600/700/800 Front Brushguard Bumper with Headlight Guards

### This Kit includes:

1. Brush guard Center (1)
2. Brush guard support mount right (1)
3. Brush guard support mount left (1)
4. Brush guard light guard right (1)
5. Brush guard light guard left (1)
6. (2) 2 3/4" L Hex Bolts
7. (4) 1" L Hex Bolts
8. (4) 1 1/3" L Hex Bolt
9. (6) 5/8" L Carriage Bolt
10. (8) 1/4" Flat Washers
11. (2) 1/3" Flat Washers
12. (6) Nylock Nuts
13. (4) Lockdown Nuts
14. (2) 1 3/4" Spacer
15. Instruction Manual (1)

1. Remove the upper retainer clips from each side of the grill assembly. Next remove the radiator shroud bolts. Fig. 1

2. Attach the Left Support Bracket to the ATV frame. Starting at the top inside corner use one 2 3/4" hex bolt, one flat washer, and one 1 3/4" spacer- do not tighten completely (**note: the spacer will install between the support bracket and the ATV frame**). Next, use two 1 1/3" hex bolts, four washers, and two lockdown nuts on the front edge of the bracket. Repeat for the Right Support Bracket Fig. 2

3. Reinstall the front grill assembly removed in step 1.

4. Bolt the Center Brushguard assembly to the Left and Right Support Brackets. Begin with the upper holes, using the front holes for 400 and 500 models or the rear holes for 600 and 700 models. Use two 1" hex bolts- do not tighten completely. Next use two 1" hex bolts and two washers to attach the bottom of the brushguard. Tighten all bolts installed in step 4. Fig 3

5. Attach the Left Headlight Guard to the Center Brushguard with three carriage bolts and three nylock nuts. Repeat for the Right Headlight Guard. Fig. 4

6. To complete installation, check all bolts and nuts for a tight fit.  
approximate install time: 30 minutes

