

## LDS Model Winches

Part#	Description	SKU name	Retail pricing
1	Motor	LDS Mtr Assem	75
2	Nut M6x20	Hex Screw	5
3	Motor base	<a href="#">Mtr Base-LDS</a>	15
4	Nut m6x20	Hex Screw	5
5	Coupling Joint	Mtr Coupler-LDS	5
6	Clutch	Brake-LDS	5
7	T series bushings	Drum Bushing-LDS	5
8	Trans shaft	Drive Shaft-LDS	5
9	Drum	<a href="#">Wnty Drum-LDS</a>	15
10	tie bar	Tie Rods-LDS	5
11	Gear Box base	FS Base-LDS	15
12	Mounting Bolt	Hardware-LDS	5
13	Washer	Hardware-LDS	3
14	Flat washer	Hardware-LDS	3
15	Nut M6x20	Mounting Nut-LDS	3
16	Flat washer	Drive Shaft-LDS	3
17	Spring	Clutch Retrn Spring-LDS	3
18	Lock washer	Drive Shaft-LDS	3
19	Left gear box	Gear Box_1-LDS	15
20	Right gear box	Gear Box_2-LDS	15
21	Gear 1	Carrier_1-LDS	15
22	Gear 2	Carrier_2-LDS	15
23	Gear 3	Carrier_3-LDS	15
24	Central; gear	Sun Gear-LDS	15
26	Bracket	FS Knob-LDS	5
27	End cover	FS Housing_3-LDS	10
29	Clutch handle assembly	<a href="#">FS Knob-LDS</a>	15
30	Roller Fairlead	ATV RFL	20
32	hook	ATV Hook	10
33	wire rope	<a href="#">Steel cable - LDS</a>	35
34	Switch assembly	<a href="#">Tswitch Wnty</a>	20
35	Relay	Contacto-LDS	25

# OUTBACK

---

## SERIES

